



NOTES:

1. IF CLEAN-OUT IS INSTALLED IN DRIVEWAY, USE CHRISTY G5 TRAFFIC VALVE BOX WITH "SEWER" CAST IN LID (OR APPROVED EQUAL). BOX SHALL HAVE A CONCRETE COLLAR. (SEE DETAIL SS-5 FOR DETAILS OF CONCRETE COLLAR)
2. WHEN PROPERTY LINE IS AT BACK OF WALK, INSTALL CLEAN-OUT BEHIND BACK OF WALK.
3. PROVIDE STOPPER WHEN THERE IS NO ON-SITE LATERAL CONNECTION.
4. MATERIAL FOR THE CLEANOUT PIPE SHALL MATCH THE MATERIAL FOR THE LATERAL. SEE CITY'S SPECIFICATIONS FOR MATERIALS.



DRAWN BY: M. LEE

CHECKED BY: S. THACH

APPROVED BY: T. SUPAN

DATE: AUGUST 2006

## SANITARY SEWER CLEAN-OUT

CITY OF SANTA CLARA

# SS-1

PAGE: 28